



GARY PLATT
UNSURPASSED

CHAIR ADJUSTMENT GUIDE

■ 2 WAY MECHANISM - SEE 1 BELOW

■ 6 WAY MECHANISM - SEE 2-4 BELOW

Both mechanisms equipped with 360° swivel



■ THE PADDLES ARE SITUATED ON THE RIGHT SIDE WHILE SEATED.

Chair Adjustment Instructions :

1. **Seat & Back Paddle** - Adjust seat and back angle together by raising the paddle.
2. **Seat Height Paddle** - To raise seat height, lift out of the chair and pull paddle upward.
To lower seat height, sit in the chair then pull upward on the paddle.
3. **Back Tilt Paddle** - Raise paddle to enable the chair's backrest to tilt forward and backward freely in both directions.
4. **Tilt Tension Knob** - Adjust knob to increase or decrease tilt tension.