

ECLIPSE



OPERATION INSTRUCTIONS

FOR FULL FUNCTION SYNCRO



ECLIPSE

OPERATION INSTRUCTIONS FOR FOLD BACK ARM

PUSH BUTTON TO ADJUST ARM HEIGHT

